


If using Variable Function 1, write a value of 63, then 62 to Modbus register 404,803 each time at power up.



User parameter settings in RED